


# TIMEX®

## Model: T1120

### Alarm Clock with USB Charging



Time Set Alarm

SET - +

- Press to decrease/increase settings

TIME SET Ⓞ

- Press and hold Time Set button to set Clock
  - Use +/- to set hour and press Time Set button to confirm
  - Use +/- to set minute and press Time Set button to confirm
- Note: Use Alarm Button to select 12/24 hour display while in time set mode

ALARMS Ⓞ


- Press & Hold Alarm button to Set Alarm
- Use +/- to select hour and press Alarm button to confirm
- Use +/- to select minute and press Alarm button to confirm
- Press and release Alarm button to arm/disarm alarm
- When alarm is sounding, press Alarm button to disarm and reset for next day

SNOOZE/DIMMER

- Press to Snooze Alarm
- Press to Adjust Display Brightness: cycle through Hi, Mid, Lo and OFF

REAR PANEL

\*Remove battery pull tab before use!




BACKUP BATTERY COMPARTMENT

(for clock accuracy and alarm setting backup)  
When Low Battery icon appears on display:

1. Make sure the AC adapter is connected, or you will lose your clock settings during battery replacement.
  2. Use a Phillips screwdriver to unscrew the battery compartment door.
  3. Remove the exhausted battery and insert a new CR2032 battery. Replace the compartment door. Do not overtighten the screw.
- Keep exhausted battery away from children and dispose of properly.

DISPLAY ICONS



\*Remove protective film in the front of display by peeling it off.

MAINTENANCE

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.