

TIMEX

Model: T242

Alarm Clock
with USB-C Charging

TOP PANEL

1 PRESS TO SET

- Press **Alarm Set** button to Set Alarm

2 ADJUST ALARM TIME

- Use +/- to select hour and minute

3 CONFIRM

- Press **Alm On/Off** button to confirm the hour or the minute

- Two beeps will sound to confirm the alarm is set, and the corresponding alarm icon will appear on the display to indicate the alarm is armed.

Note: Observe the PM indicator to confirm that you have set the hour correctly.

- Press and release **Alm On/Off** button to arm/disarm alarm

- Adjust the alarm volume using the switch on the back of the unit.

- Press the corresponding Alarm Set button or the **Alm On/Off** button to turn off the alarm.



Snooze Alarm

When alarm is sounding, press **SNOOZE/DIMMER** to delay the alarm for 9 minutes. This can be pressed numerous times up to one hour.

Display Dimmer Control

To adjust the brightness of the display, press **SNOOZE/DIMMER** repeatedly to cycle through Hi, Med, Lo, and OFF.

FRONT PANEL

DISPLAY ICONS

* Remove protective film in the front of display by peeling it off.




BATTERY INSTALLATION

(For clock accuracy and alarm setting backup)

When Low Battery icon appears on display:

1. Make sure the AC adapter is connected, or you will lose your clock settings during battery replacement.
2. Press in on the battery door to open and remove the battery door.
3. Install new 2 "AAA" batteries, matching the (+/-) markings in the battery compartment. Replace the door. (Keep new and used batteries away from children.)



MAINTENANCE

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.

REAR PANEL



DC JACK (5V/1.2A) (for power supply)



AC Adapter

Connect the included AC adapter to the DC jack located on back of the unit and plug into a working outlet not controlled by an On/Off switch.



USB-C Charging Function

To charge your mobile device, connect the USB-C charging cable that was supplied with your device to the USB charging port on the back panel of this alarm clock. The output rating of the USB charging port is 1 Amp.



TIME SET

- Press and hold the **Time Set** Button for 2 seconds until display starts to flash and 1 beep sounds. Release the **Time Set** Button.
- Use +/- to set hour and press **Time Set** button to confirm
- Use +/- to set minute and press **Time Set** button to confirm
- Two beeps will confirm setting.

Note: Use **Alarm Set** Button to select 12/24 hour display while in time set mode. If you are using the 12 hour clock, be sure to check the PM indicator to make sure you are setting the clock for the right time of day.



To adjust the alarm sound using the Alarm Volume switch to Hi and Lo

BATTERY CAUTIONS AND TIPS

- Caution - Risk of explosion if the battery is replaced by an incorrect type.
- Only use the recommended/supplied batteries or equivalent.
- Use alkaline batteries for longer life.
- Do not mix old and new batteries, and do not mix alkaline, carbon-zinc or rechargeable nickel-cadmium batteries.
- Insert batteries with proper polarity (+/-) as indicated.
- Remove exhausted batteries from product.
- Do not attempt to recharge non-rechargeable batteries.
- Do not open batteries or heat them beyond normal ambient temperatures.
- To prevent battery leakage or damage, remove batteries from a product if it will not be used for a month or longer.
- Use extreme caution handling leaking batteries (avoid direct contact with eyes and skin). If battery leakage comes in contact with eyes, IMMEDIATELY flush the eye with lukewarm and gently flowing water for at least 30 minutes. If skin contact occurs, wash skin with clean water for at least 15 minutes. Seek medical attention if any symptoms occur.
- Store in cool, dry, ventilated area away from hazardous or combustible material.
- Follow applicable laws and local regulations for the disposal and transportation of batteries.

IMPORTANT SAFETY INSTRUCTIONS

Please heed all warnings, read and follow all instructions and keep these instructions handy for future reference.

1. Do not use this product near water.
2. Unplug unit and clean only with damp cloth. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.
3. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
4. Heat - This product should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
5. Only use attachments/accessories specified by the manufacturer.
6. Unplug this product during lightning storms or when unused for long periods of time.
7. Damage Requiring Service - This product should be serviced by qualified service personnel when:
 - Plug has been damaged.
 - Objects have fallen into or liquid has been spilled into the enclosure.
 - The unit has been exposed to rain. The unit has been dropped or the enclosure damaged.
 - The unit exhibits a marked change in performance or does not operate normally.
8. No naked flame sources, such as lighted candles, should be placed on this product.
9. Attention should be drawn to the environmental aspects of battery disposal. Many electronics retailers now recycle batteries and other electronic components at no charge. To find a drop-off location near you, visit www.cal2recycle.com
10. This product is suitable for use in tropical and/or moderate climates.

WARNING:

- To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- Do not dispose of batteries in the household trash or fire.
- The mains plug of power adaptor is used as the disconnect device, it shall remain readily operable.

FCC Information

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum distance 20cm (8 inches) between the radiator & your body.

ISED Information

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
 - (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- The device complies with ISED RF exposure requirement, users can obtain Canadian information on RF exposure and compliance. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appareil est conforme aux exigences d'exposition RF ISED, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité.

Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur à utiliser l'équipement.

CAN ICES-3 (B) / NMB-3(B)

LIMITED 30 DAY WARRANTY

For product support and warranty please visit: www.hoteltech.com/support

© 2023 HTI Industries, LLC. All rights reserved

Questions? Visit www.hoteltech.com

TIMEX trademark owned by Timex Group USA, Inc. in the US and other countries

T242_IS_102522-A

Printed in China